Vintage Turntable With CD / Cassette / Radio / Aux-In / USB / SD / MP3 and Vinyl-to-MP3 Encoding

PTCDS5U

INSTRUCTION MANUAL

LOCATION OF CONTROLS



1) DIAL POINTER
2) LCD DISPLAY
3) FUNCTIONS SWTICH
4) POWER LED INDICATOR
5) POWER ON/OFF, VOLUME UP/DOWN KNOB
6) MP3 FOLDER UP BUTTON
7) SOURCE BUTTON
8) EXTRA BASS ON/OFF BUTTON
9) RECORD● BUTTON
10) CD DOOR
11) SD/MMC CARD SLOT
12) RADIO BAND SELECTOR SWTICH
13) FM STEREO LED INDICATOR
14) TUNING KNOB
15) REMOTE SENSOR
16) SKIP/SEARCH DOWN⏮ BUTTON
17) SKIP/SEARCH UP⏭ BUTTON
18) CD DOOR OPEN BUTTON
19) PLAY/PAUSE/STOP⏯/■ BUTTON
20) USB SOCKET
21) 3.5 MM HEADPHONE JACK
22) TAPE FORWARD / EJECT BUTTON
23) CASSETTE DOOR COVER
24) SPINDLE ADAPTOR
25) 33/45 RPM SPEED SELECTOR
26) PICK-UP HOLDER
27) FM WIRE ANTENNA
28) LINE OUT SOCKET (L/R)
29) AUTO STOP SWITCH
30) AC CORD

CAUTION:
USAGE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULTE IN HAZARDOUS RADIATION EXPOSURE.
THIS UNIT SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT QUALIFIED SERVICE PERSONNEL.

PRECAUTIONS FOR USE

INSTALLATION

- UNPACK ALL PARTS AND REMOVE PROTECTIVE MATERIAL.
- DO NOT CONNECT THE UNIT TO THE MAINS BEFORE CHECKING THE MAINS VOLTAGE AND BEFORE ALL OTHER CONNECTIONS HAVE BEEN MADE.
- DO NOT COVER ANY VENTS AND MAKE SURE THAT THERE IS A SPACE OF SEVERAL CENTIMETERS AROUND THE UNIT FOR VENTILATION.

CONNECTION

1. CONNECT THE POWER CORD (30) TO AC OUTLET.
2. TURN ON THE POWER (5) UNTIL THE LCD DISPLAY (2) WITH BLUE BACKLIGHT ON.
3. THEN SWITCH THE FUNCTION SELECTOR (3) TO " TUNER " FUNCTION. IF SOUND IS COMING OUT FROM THE SPEAKER, IT'S MEAN THE POWER SUPPLY IS NORMAL. NOW YOUR SYSTEM IS READY TO PLAY THE MUSIC.

LISTENING TO RADIO

MANUAL TUNING

1. SELECT THE DESIRED BAND BY RADIO BAND SELECTOR (12) (AM OR FM OR FM-STEREO).
2. TUNE TO THE REQUIRED STATION BY TURNING THE TUNING KNOB (14).
3. ADJUST VOLUME KNOB (5) TO THE DESIRE VOLUME LEVEL.

FM & FM-STEREO RECEPTION

- SET THE RADIO BAND SELECTOR (12) AT " FM " POSITION. PROGRAMS ARE RECEIVED IN MONO MODE. IN PARTICULAR WHEN STEREO SIGNAL ARE WEAK. IT IS PREFERABLE TO RECEIVE THE PROGRAM IN MONO.

- SET THE RADIO BAND SELECTOR (12) AT "FM-ST" POSITION FOR RECEIVING STEREO PROGRAMS. THE FM-STEREO LED INDICATOR (13) WILL LIGHT UP TO SHOW FM STEREO PROGRAM IS RECEIVING.

HINTS FOR BEST RECEPTION:-

- AM : THE RECEIVER HAS A BUILT-IN AM BAR ANTENNA. IF AM RECECPTION IS WEAK, SLIGHTLY ROTATE OR RE-POSITIONING OF THE UNIT WILL USUALLY IMPROVE THE AM RECEPTION.
- FM : THE RECEIVER HAS A BUILT-IN FM WIRE ANTENNA (27) HANGING AT THE REAR CABINET. THIS WIRE SHOULD BE TOTALLY UNRAVELED AND EXTENDED FOR BEST RECEPTION.

PLAYING COMPACT DISC

- **GETTING START**

1. TURN FUNCTION SELECTOR (3) TO SELECT " CD/USB/SD " MODE.
2. PRESS "OPEN/CLOSE" BUTTON (18) TO OPEN THE CD DOOR (10).
3. PLACE A CD WITH THE PRINTED SIDE FACING UP INSIDE THE TRAY & THEN CLOSE THE CO DOOR.
4. FOCUS SEARCH IS PERFORMING, THE LCD DISPLAY (2) WILL SHOW THE TOTAL NUMBER OF TRACKS & TOTAL PLAYING TIME.

- **PLAY / PAUSE / STOP MODE ▶II / ■**

1. PRESS THE " PLAY/PAUSE/STOP " BUTTON (19) TO START PLAYBACK, THE FIRST TRACK WILL START PLAYBACK.
2. TO INTERRUPT, PRESS THE " PLAY/PAUSE/STOP " BUTTON (19) ONCE, THE PLAYING TIME WILL BE FREEZE & FLASHING ON THE LCD DISPLAY (2). PRESS AGAIN TO RESUME NORMAL PLAYBACK.
3. IF PRESS AND HOLD THE " PLAY / PAUSE STOP " BUTTON (19) FOR OVER 2 SECONDS DURIGN PLAYBACK MODE. THE SYSTEM WILL GO TO STOP MODE.

- **SKIP/SEARCH MODE (SKIP/SEARCH UP ▶▶I / SKIP/SEARCH DOWN I◀◀)**

1. DURING PLAY OR PAUSE MODE, IF "SKIP UP" BUTTON (16) IS PRESSED. IT WILL GO TO NEXT TRACK AND DISPLAY THE TRACK NO. AND THEN REMAIN THE PLAY OR PAUSE MODE.
2. DURING PLAY OR PAUSE MODE, IF "SKIP DOWN" BUTTON (17) IS PRESSED. IT WILL GO BACK TO THE BEGINNING OF THE TRACK, ORIGINAL TRACK NO. IS DISPLAY AND REMAIN THE PLAY OR PAUSE MODE.
3. AFTER STEP 2, PRESS "SKIP DOWN" BUTTON (17) AGAIN WILL GO TO THE PREVIOUS TRACK AND REMAIN THE PLAY OR PAUSE MODE.
4. IF PRESS AND HOLD THE " SKIP UP/DOWN BUTTON " (16,17) DURING CD/MP3 FILE PLAYABCK, THE PLAYING TRACK WILL GO FAST FORWARD OR BACKWARD UNTIL THE BUTTON BEING RELEASED.

- **FOR MP3 DISC**

1. PRESS " MP3 FOLDER " UP BUTTON (6), THE FOLDER NO. WILL GOES UP
2. PRESS " SKIP UP ▶▶I " OR SKIP DOWN I◀◀ (16,17) BUTTON, THE TRACK NO. CHANGE.
3. WHEN THE DESIRED TRACK IS BEING SELECTED, PRESS THE " PLAY/PAUSE/STOP " BUTTON (19) TO START PLAYBACK.

ID3 (TRACK/ALBUM TITLE) FUNCTION (BY REMOTE HANDSET)

1. PRESS THE " INFO " BUTTON DURING PLAYBACK OF MP3/WMA DISC, THE SONG TITLE IS BEING DISPLAYED. PRESS THE " INFO " BUTTON AGAIN TO DISABLE THE FUNCTION.

SONG TITLE/FOLDER NAME SEARCH FUNCTION (BY REMOTE HANDSET)

YOU CAN SEARCH THE TRACK BY THE TITLE/FLODER NAME IN DISC DURING STOP MODE:-

1. PRESS THE " FIND " BUTTON ONCE, THEN PRESS THE "SKIP UP" (OR SKIP DOWN) BUTTON (16,17), YOU CAN SEARCH THE TITLE OF EACH SONG ONE BY ONE UNDER ALPHABET ORDER ON LCD DISPLAY (2), THEN PRESS THE CD " PLAY/PAUSE/STOP " BUTTON (19) TO START THE PLAYBACK OF THE SELECTED TRACK.
2. PRESS AGAIN " FIND " BUTTON, THE FOLDER NAME IS BEING DISPLAYED. THEN PRESS THE "SKIP UP" (OR SKIP DOWN) BUTTON (16,17) TO SELECT THE DESIRED FOLDER, AND PRESS THE CD" PLAY/PAUSE/STOP " BUTTON (19) TO START THE PLAYBACK OF ALL TRACKS INSIDE THAT SELECTED FOLDER.

REMARK:-

- IN THAT CASE OF NO NAME HAD BEEN ASSIGNED FOR THE TRACK, " NONE " OR " UNKNOWN " IS BEING DISPLAYED" ON LCD DISPLAY (2).

- THE SYSTEM SUPPORT ENGLISH ALPHABET AND NUMERAL ONLY FOR ID3 TEXT

MP3/WMA TRACK FORMAT REQUIREMENT:-

- MP3 BIT RATE : 32 KBPS~256 KBPS AND WMA BIT RATE : 32 KBPS ~ 320 KBPS
- THE PERFORMANCE OF PLAYING MP3 DISC IS VARIOUS FROM THE QUALITY OF RECORDING DISC AND THE METHOD OF RECORDING. FURTHERMORE, THE SEARCHING LEAD-TIME FOR MP3-CD IS LONGER THAN NORMAL CD DUE TO DIFFERENCE FORMAT.

- **REPEAT/INTRO/RANDOM MODE (BY REMOTE CONTROL)**

PRESS THE REPEAT/INTRO/RANDOM BUTTON BEFORE OR DURING PLAYBACK, A SINGLE TRACK, SINGLE FOLDER (MP3 FILE ONLY) OR ALL THE TRACKS CAN BE PLAYED IN DIFFERENCE MODE AS FOLLOW:-

FOR CD

(1) REPEAT 1 → (2) REPEAT ALL TRACK → (3) INTRO → (4) RANDOM → (5) OFF MODE

PLAY MODE	INDICATOR ON LCD DISPLAY
REPEAT TRACK	↻
REPEAT ALL	↻ ALL
INTRO	INTRO
RANDOM	RANDOM
OFF MODE	----------

FOR MP3 DISC

(1) REPEAT 1 → (2) REPEAT 1 FOLDER → (3) REPEAT ALL FOLDER → (4) INTRO PLAY → (5) RANDOM → (6) OFF MODE → (1) REPEAT 1

PLAY MODE	INDICATOR ON LCD DISPLAY
REPEAT SINGLE TRACK	↻
REPEAT ALL TRACKS	↻ ALL
REPEAT SINGLE FOLDER	↻ FOLDER
INTRO PLAY MODE	INTRO
RANDOM MODE	RANDOM
OFF MODE	----------

- **REPEAT PLAY**

YOU CAN LISTEN THE DESIRED TRACK OR FOLDER REPEATEDLY BY THIS FUNCTION.

- **INTRO PLAY**

YOU CAN LISTEN THE BEGINNING (10 SECONDS) OF EACH TRACK IN A CD BY THIS FUNCTION & SAVING YOUR TIME TO SEARCH THE DESIRE SONG

- **RANDOM PLAY**

YOU CAN LISTEN ALL THE TRACKS OR FOLDER IN A RANDOM ORDER BY THIS FUNCTION

CD/MP3 DISC PROGRAMMING (BY REMOTE CONTROL)

UP TO 32 TACKS CAN BE PROGRAMMED FOR CD OR MP3 FILE AND PLAY IN ANY ORDER. BEFORE USE, BE SURE THE SYSTEM IS AT STOP MODE BEFORE PROGRAMMING:-

1. SET IN CD/USB/SD MODE & STOP THE CD/MP3 DISC PLAYBACK.
2. PRESS THE "PROGRAM" BUTTON, " PROG " INDICATOR WILL APPEAR ON LCD DISPLAY (2). MOREOVER,

IT WILL INDICATE PROGRAM NO. AND DIGITS FOR TRACK NO. TO BE PROGRAMMED.

3. SELECT A DESIRED TRACK BY PRESSING SKIP ⏭ OR ⏮ BUTTONS (16,17).
4. PRESS THE " PROGRAM " BUTTON TO STORE THE TRACE INTO MEMORY.
5. REPEAT STEPS 3 AND 4 TO ENTER ADDITIONAL TRACKS INTO THE MEMORY IF NECESSARY.
6. WHEN ALL THE DESIRED TRACKS HAVE BEEN PROGRAMMED, PRESS CD " PLAY/PAUSE/STOP " ⏯/■ BUTTON (19) TO PLAY THE DISC IN ASSIGNED ORDER.
7. TO CANCEL THE PROGRAMMED FILE, PRESS "STOP" BUTTON ON REMOTE HANDSET UNTIL " PROG " INDICATOR IS DISAPPEAR ON LCD DISPLAY (2)

PLAYBACK OF MP3/WMA SONG VIA USB STORAGE MEDIA OR MEMORY CARD

CONNECTING

THE SYSTEM IS ABLE TO DECODE AND PLAYBACK ALL MP3 /WMA FILE WHICH STORED IN THE MEMORY MEDIA WITH USB CONNECTING PORT OR SD/MMC MEMORY CARD.

1. SET FUNCTION SELECTOR (3) AT CD/USB/SD MODE AND THEN PRESS SOURCE BUTTON (7) TO SELECT " USB OR CARD" MODE.
2. PLUG-IN THE USB PLUG WITH THE FACE UP & MAKE SURE IT GOING INTO COMPLETELY OR INSERT THE MEMORY CARD IN THE DIRECTION OF THE ARROW AS SHOWN IN THE LABEL ON THE UNDERSIDE OF THE MEMORY CARD SLOT COVER. INSERT STRAIGHT WITHOUT BENDING.



- **CONNECTING THE USB UPSIDE DOWN OR BACKWARDS COULD DAMAGE THE AUDIO SYSTEM OR THE STORAGE MEDIA (USB THUMB DRIVE / SD/MMC CARD). CHECK TO BE SURE THE DIRECTION IS CORRECT BEFORE CONNECTION.**

3. THE SYSTEM WILL START READING THE STORAGE MEDIA AUTOMATICALLY AFTER CONNECTING, AND LCD DISPLAY (2) WILL SHOW THE TOTAL NUMBER OF MP3/WMA FILES AND TOTAL NUMBER OF FOLDER BEING DETECTED.
4. REPEAT THE SAME PLAYBACK PROCEDURE AS PLAYING CD/MP3 DISC AS ABOVE

REMARK

- THE SYSTEM CAN DETECT AND READ THE FILE UNDER MP3 AND WMA FORMAT ONLY THOUGH THE USB SOCKET OR SD/MMC CARD.
- **IF CONNECT THE SYSTEM TO MP3 PLAYER VIA THE USB SOCKET, DUE TO VARIANCES IN MP3 ENCODING FORMAT, SOME MP3 PLAYER MAY NOT BE ABLE TO PLAY VIA THE USB SOCKET. THIS IS NOT A MAUFUNCTION OF THE SYSTEM.**
- **USB PORT DOES NOT SUPPORT CONNECTION WITH USB EXTENSION CABLE AND IS NOT DESIGNED FOR COMMUNICATION WITH COMPUTER DIRECTLY.**

LISTING TO TAPE

GENERAL OPERATION

CASSETTE PLAYBACK : THE SYSTEM WILL START THE PLAYBACK AUTOMATICALLY AFTER INSERTING OF CASSETTE TAPE

STOP AND EJECTION : PRESS THE " TAPE FORWARD / EJECT " BUTTON COMPLETELY INWARDS AND THE CASSETTE TAPE WILL BE EJECTED THOUGH THE CASSETTE DOOR COVER. THE " TAPE FORWARD / EJECT " BUTTON WILL KEEPING AT LOWEST HEIGHT POSITION.

FAST FORWARD : PRESS THE " TAPE FORWARD / EJECT " BUTTON HALF INWARDS DURING PLAYBACK MODE, THE TAPE WINDING FORWARD DIRECTION. THE " TAPE FORWARD / EJECT " BUTTON WILL KEEPING AT MIDDLE HEIGHT POSITION.

SLIGHTLY PRESS THE " TAPE FORWARD / EJECT " BUTTON AGAIN TO RESUME NORMAL PLAYBACK. THE " TAPE FORWARD / EJECT " BUTTON WILL RESUME TO THE HIGHEST POSITION.



REMARK

- MAKE SURE THE DIRECTION IS CORRECT WHEN INSERTING THE TAPE INTO THE SYSTEM.
- THERE IS SOME SEARCHING NOISE CAN BE HEARD AND THE SYSTEM CANNOT PERFORM NORMAL PLAYBACK FUNCTION DURING FAST FORWARD MODE.
- THIS IS RECOMMENDED TO TAKE OUT THE CASSETTE TAPE FROM THE SYSTEM EVERY TIMES AFTER LISTENING AND DON'T LEAVE THE CASSETTE TAPE INSIDE THE SYSTEM WHEN NOT UNDER PLAYBACK MODE.



PHONO

NOTED:

- REMOVE THE STYLUS PROTECTOR.
- BE SURE THAT THE TONE ARM IS BEING DETACHED FROM THE TONE ARM REST BEFORE OPERATING AND RE-SECURED AGAIN AFTERWARDS.



1. SELECT TO " PHONO " FUNCTION FROM FUNCTION SELECTOR (3)
2. SET THE SPEED SELECTOR TO THE PROPER POSITION DEPENDING ON THE RECORD TO BE PLAYED.
3. PLACE THE RECORD ON THE PLATTER (USE THE SPINDLE ADAPTOR IF REQUIRED).
4. LIFT THE TONE ARM FROM THE REST AND SLOWLY MOVE IT TO THE RECORD SIDE. THE PLATTER WILL START TO ROTATE.
5. PLACE THE TONE ARM TO THE DESIRED POSITION OF THE RECORD.
6. ADJUST THE VOLUME TO THE DESIRED LEVEL.
7. AT THE END OF RECORD, THE PLATTER WILL AUTOMATICALLY STOP ROTATING. LIFT THE TONE ARM FROM THE RECORD AND RETURN IT TO THE REST.
8. TO STOP MANUALLY, LIFT THE TONE ARM FROM THE RECORD AND RETURN IT TO THE REST.



REMARK : AS SOME KIND OF RECORD THE AUTO-STOP AREA WAS OUT OF THE UNIT SETTING, SO IT WILL STOP BEFORE THE LAST RACK FINISH. IN THIS CASE, SELECT THE AUTO-STOP SWITCH (29) TO " OFF " POSITION, THEN IT WILL RUN TO THE END OF THE RECORD BUT WILL NOT STOP AUTOMATICALLY (TURN OFF THE UNIT BY POWER BUTTON OR SWITCH BACK THE AUTO-STOP SWITCH TO " ON " POSITION TO STOP THE PLATTER ROTATE). THEN PUT BACK THE TONE ARM TO THE REST POSITION.

LINE OUT CONNECTION

YOU CAN CONNECT THE SYSTEM TO YOUR WHOLE HI-FI SYSTEM BY CONNECTING THE LINE OUT SOCKET (28) TO THE AUXILIARY INPUT SOCKET WITH A RCA CABLE (NOT INCLUDED).

ENCODING OF CD DISC / PHONO OR CASSETTE TAPE INTO MP3 FILE

THE SYSTEM IS ABLE TO ENCODE CD, RECORD (FROM PHONO) AND CASSETTE DECK FILE (FROM TAPE) TO MP3 FORMAT AND RECORDING AT MEMORY MEDIA WITH USB CONNECTING PORT OR SD/MMC CARD.

A) CD ENCODING

I) RECORDING 1 TRACK

1. PLUG IN THE USB PEN DRIVE FOR RECORDING (MAKE SURE IT AHD ENOUGH EMPTY SPACE).
2. PLAY THE CD TRACK YOU WANT TO ENCODE/RECORD, AS NORMAL.
3. PRESS THE " RECORD " BUTTON (9) DURING PLAYBACK OF THE DESIRED TRACK
4. " ⇆ " & " REC " WILL BE FLASHING ON THE LCD DISPLAY (2) TO SHOW ENCODING IS IN PROGRESS.
5. AFTER THE ENCODING PROCESS HAS FINISHED, THE UNIT WILL STOP PLAYBACK AUTOMATICALLY.

II) RECORDING THE COMPLETE CD

1. PLACE A CD WITH THE PRINTED SIDE FACING UP INSIDE THE CD TRAY & THEN CLOSE THE CD DOOR.
2. AFTER DISC SEARCH HAS BEEN COMPLETED, PRESS THE " RECORD " BUTTON (9) – **NOTE:** DO NOT PRESS " PLAY/PAUSE/STOP " BUTTON (19) AND THEN "RECORD" BUTTON, OR ONLY THE SELECTED TRACK WILL BE RECORDED.
3. " ⇆ " & " REC " WILL BE FLASHING ON THE LCD DISPLAY (2) TO SHOW ENCODING IS IN PROGRESS.
4. AFTER THE ENCODING PROCESS HAS FINISHED, THE UNIT WILL STOP PLAYBACK AUTOMATICALLY.

III) ENCODING BY PROGRAM

1. PLACE A CD WITH THE PRINTED SIDE FACING UP INSIDE THE TRAY & THEN CLOSE THE CO DOOR
2. SELECT THE DESIRE TRACKS BY FOLLOWING " **CD/MP3 DISC PROGRAMMING** " PROCEDURES. THEN PRESS " PLAY/PAUSE/STOP " BUTTON (19) TO START PLAYBACK.

3. PRESS THE " RECORD " BUTTON (3) AND THE UNIT WILL DISPLAY " ⇆ " & " REC " & FLASHING. ENCODING IS PERFORMING NOW.
4. AFTER COMPLETING OF ENCODING, UNIT WILL STOP PLAYBACK AUTOMATICALLY.

REMARK:-
- INSERT EITHER ONE TYPE OF MEMORY MEDIA (USB PEN DRIVE OR SD/MMC CARD) TO THE UNIT FOR ENCODING PROCESS FROM CD/PHONO/TAPE RESPECTIVELY.
- THE RECORDING SPEED IS 1:1 AND ACCORDING TO THE ACTUAL PLYING TIME OF THE PHONO OR TAPE
- DURING COPY MODE, THE SYSTEM WILL COPY THE MP3/WMA FILE ONLY.
- THE SYSTEM WILL CRATE A " AUDIO " FOLDER FOR ENCODING FILE AND " FCOPY " FOR COPYING FILE.

- THE RECORDING FORMAT IS PRESET AT – MP3 BIT RATE : 128 KBPS, SAMPLING RATE : 44.1KHZ
- NO SONG TITLE WILL BE RECORDED DURING ENCODING MODE
- TO INTERRUPT THE RECRODING, PRESS THE " RECORD " BUTTON AGAIN DURING RECORD MODE.
- THE SYSTEM WILL STORE THE FILE TO USB SORCE FIRST IF BOTH USB AND SD SLOT ARE BEING OCCUPLIED DURING ENCODING OF PHONO OR TAPE MODE.
- **ENCODING CD TO MP3 FILE OR COPYING MP3 FILE FROM USB/SD WILL BE SUCCESSFUL ONLY ENTIRE SONG BEING ENCODED OR COPIED, IF TERMINATE THE ENCODING OR COPYING PROCESS INTERMEDIATELY, THERE IS NO TRACK BEING RECORDED NOR STORED TO THE USB OR SD/MMC CARD**

IV) COPYING OF MP3/WMA FILE

IF PUTTING A MP3/WMA DISC INSTEAD OF A CD-DISC, THE SYSTEM WILL COPY THE FILES TO THE USB OR SD/MMC CARD IF PRESS THE " RECORD " BUTTON (9). THE OPERATION PROCEDURES IS SAME AS CD ENCODING AS STIPULATE ON ABOVE, AND THE SYSTEM WILL SWITCH TO COPYING MODE ONLY IF MP3/WMA FILE BEING READ.

REMARK:
- THE SYSTEM WILL STORE THE FILE TO USB SORCE FIRST IF BOTH USB AND SD SLOT ARE BEING OCCUPLIED BY STORAGE MEDIA.
- IF PRESS THE " RECORD " BUTTON (9) DURING PLAYBACK OF USB OR SD SOURCE, THE FILE WILL COPY FROM USB TO SD OR SD TO USB.

B) PHONO ENCODING

1) PLUG IN THE USB PEN DRIVE FOR RECORDING (MAKE SURE IT AHD ENOUGH EMPTY SPACE).
2) SET THE FUNCTION BUTTON (3) TO " PHONO " POSITION AND THEN PRESS THE " RECORD " BUTTON (9) DIRECTLY.
3) THE LCD DISPLAY (2) WITH SHOW THE WORD " **USB** " AND FLASHING, AFTER THEN DISPLAY " ⇆ " & " REC " AND FLASHING. NOW THE SYSTEM IS STARTING THE ENCODING MODE.
4) START PLAYBACK AT PHONO FOR THE TRACK WHICH YOU WANT TO RECORD TO USB OR SD CARD.
5) AFTER FINISH OF RECODING, PRESS AND HOLD THE " RECORD " BUTTON (9) UNTIL THE TEXT ON LCD DISPLAY (2) STOP FLASHING AND RETURN TO " PHONO " MODE.

C) CASSETE ENCODING

1) PLUG IN THE USB PEN DRIVE FOR RECORDING (MAKE SURE IT AHD ENOUGH EMPTY SPACE).
2) SET THE FUNCTION BUTTON (3) TO " TAPE " MODE AND THEN PRESS THE " RECORD " BUTTON (9) DIRECTLY.
3) THE LCD DISPLAY (2) WITH SHOW THE WORD " **USB** " AND FLASHING, AFTER THEN DISPLAY " ⇆ " & " REC " AND FLASHING. NOW THE SYSTEM IS STARTING THE ENCODING MODE.
4) START PLAYBACK OF CASSETTE TAPE WHICH THE TRACK YOU PREPARE TO RECORD.
5) AFTER FINISH OF RECODING, PRESS AND HOLD THE " RECORD " BUTTON (9) UNTIL THE SYMBOL " ⇆ " & " REC " DISAPPEAR AND REUME TO " TAPE " MODE ON LCD DISPLAY (2).

D) FILE COPY FROM USB TO SD OR VICE VERSA

THE SYSTEM ALLOW TO COPY THE FILES FROM THE USB SORUCE TO SD/MMC CARD BY PRESSING THE " RECORD " BUTTON (9):-

I) COPYING 1 TRACK (ASSUME COPY FROM SD CARD TO USB MODE)

1. PERFORM NORMAL PLAYBACK OF THE TRACK AT SD/MMC CARD YOU WANT TO COPY,
2. PRESS " RECORD " BUTTON (9) DURING THE PLAYBACK OF THE DESIRE TRACK, UNIT WILL DISPLAY " ⇆ " & " REC " AND FLASHING. COPYING IS PERFORMING NOW.
3. AFTER COPYING IS COMPLETED, UNIT WILL STOP PLAYBACK AUTOMATICALLY.

II) COPYING ALL TRACKS (ASSUME COPY FROM SD CARD TO USB MODE)

1. SELECT " SD " MODE AND THEN INSERT THE SD/MMC CARD YOU WANT TO COPY.

2. AFTER READING OF CARD INFORMATION IS COMPLETED, PRESS THE " RECORD " BUTTON (9) AND THE UNIT WILL DISPLAY " ⇐ " & " REC " AND FLASHING. COPYING IS PERFORMING NOW.
3. AFTER COPYING IS COMPLTED, UNIT WILL STOP AUTOMATICALLY.

E) ENCODING BITRATE (BY REMOTE HANDSET)

YOU CAN SELECT THE DESIRED BITRATE DURING ENCODING, THE HIGHER BIT RATE WILL GENERATE BETTER SOUND QUALITY AND OCCUPY MORE SPACE OF MEMORY. THE SELECTABLE RANGE IS FROM 32 / 64 /96 /128 / 192 / 256 KBPS RESPECTIVELY

1. SET IN " PHONO " FUNCTION (3) & REMAIN STOP MODE.
2. PRESS THE " INFO " BUTTON AT REMOTE HANDSET AND THE LCD DISPLA (2) WILL SHOW THE DEFAULT BITRATE (128 KBPS)
3. PRESS SKIP ⏭ OR ⏮ BUTTONS (16,17) TO SELECT THE DESIRE BITRATE FOR ENCODING.
4. PRESS AGAIN THE " INFO " TO CONFIRM THE SETTING AND THE LCD DISPLAY (2) WILL RESUME TO " PHONO " MODE

F) TRACK SEPARATION (BY REMOTE HANDSET)

YOU CAN DIVIDE THE RECORDING MUSIC FROM PHONO OR TAPE TO USB/SD TRACK BY TRACE DURING ENCODING. EVERY TIME WHEN PRESS THE " TS " (TRACK SEPARATION) BUTTON ONCE AT REMOTE HANDSET DURING ENCODING FROM PHONO OR TAPE TO USB/SD, THE SYSTEM WILL GENERATE A NEW TRACK AND CONTINUOUS THE RECRODING. THE TEXT " PHONO " OR " TAPE " AT LCD DISPLAY (2) WILL FLASHING ONE TIME, IT MEAN THE UNIT IS CREATING A NEW TRACK SUCCESSFULLY.

FILE DELETE AT USB / SD CARD (BY REMOTE CONTROL)

THE SYSTEM IS ABLE TO ERASE THE FILE STORED INSIDE THE USB PEN DRIVE OR SD/MMC CARD BY FOLLOWING:-

A) SINGLE FILE DELETE

1 . SELECT AT " USB " OR " SD " MODE.

2 . PRESS AND HOLD THE " INFO " BUTTON FOR 3 SECONDS AND THE LCD DISPLAY (2) WILL SHOW (DEL ---001)

3 . PRESS SKIP FORWARD⏭ OR SKIP BACKWARD⏮ BUTTON TO SELECT THE FILE GOING TO DELETE

4 . PRESS THE " REC● " BUTTON TO ENTER " YES / NO " MODE AND THEN PRESS SKIP FORWARD⏭ OR SKIP BACKWARD⏮ TO SELECT " YES " OR " NO ".

5 . PRESS THE " REC● " BUTTON AGAIN TO CONFIRM THE SETTING.

B) ALL FILES DELETE (BY REMOTE CONTROL)

1. SELECT AT " USB " OR " SD " MODE.
2. PRESS AND HOLD THE " INFO " BUTTON FOR 3 SECONDS AND THE LCD DISPLAY (2) WILL SHOW (DEL ---001)
3. PRESS AND HOLD THE " INFO " BUTTON AGAIN AND THE LCD WILL SHOW " FORMAT / Y/N " AND FLASHING. THEN PRESS SKIP FORWARD⏭ OR SKIP BACKWARD⏮ TO SELECT " Y (YES) " OR " N (NO) ".
4. PRESS THE " REC● " BUTTON AGAIN TO CONFIRM THE SETTING.

REMARK :

- ALL THE FILES INSIDE THE USB STORAGE MEDIA OR SD CARD WILL BE DELETED COMPLETELY AFTER CONFIRMING TO " Y (YES) " MODE.
- PRESS " STOP " BUTTON ONCE AT REMOTE HANDSET TO QUITE DELETE MODE

REMOVING OF USB / MEMORY CARD

TO REMOVE THE USB / MEMORY CARD, TURN OFF THE POWER OR SWITCH THE FUNCTION MODE TO EITHER CD, TAPE OR TUNER FIRST. FOR USB PORT – UN-PLUG IT BY PULLING OUT THE USB SOCKET DIRECTLY, FOR MEMORY CARD – PRESS THE MEMORY CARD INWARD & THEN RELEASE, NOW THE CARD BEING PARTIALLY EJECT AND YOU CAN REMOVE IT BY HAND.

X-BASS SOUND EFFECT

PRESS THE X-BASS BUTTON (8) TO ACTIVE X-BASS FUNCTION AND EHNANCE THE BASS EFFECT AT " ON ▂▃▅▃" POSTION.

REMOTE CONTROL TRANSMITTER



BATTERY INSTALLATION (BATTERY N
THE INFRA-RED TRANSMITTER REQUIRES :RY FOR OPERATION

BUTTON DESCRIPTION

1) FIND	IN MP3/WMA PLAYBACK, PRESS TO ACTIVE FILE/FOLDER NAME SEARCH FUNCTION.
2) INFO	IN MP3 PLAYBACK MODE : PRESS TO ACTIVE ID3 FUNCTION IN PHONO MODE : PRESS TO SELECT ENCODING BITRATE
3) REC●	PRESS TO ACTIVE ENCODING OR RECRRDING FUNCTION
4) REP/INTRO/RAN	IN SD/USB MODE, PRESS TO ACTIVE REPEAT / INTRO / RANDOM FUNCTION
5) PROGRAM	IN SD/USB MODE, PRESS TO ACTIVE PROGRAMMING FUNCTION
6) PLAY/PAUSE▶II	IN SD/USB MODE, PRESS ONCE TO START PLAYBACK. PRESS AGAIN TO ENTER PAUSE MODE.
7) SKIP/SEARCH FORWARD▶▶I	PRESS ONCE TO SKIP TO NEXT TRACK, PRESS & HOLD FOR SEARCH FORWARD
SKIP/SEARCH BACKWARDI◀◀	PRESS ONCE TO SKIP TO PREVIOUS TACK.PRESS & HOLD FOR SEARCH BACKWARD

8) STOP■	IN SD/USB MODE, PRESS TO STOP PLAYBACK OR CANCEL THE STORED PROGRAM.
9) FOLDER UP▲/DOWN▼	IN SD/USB MODE, PRESS TO SELECT FOLDER UP OR DOWN
10) SOURCE	IN SD/USB MODE, PRESS TO SELECT SD OR USB MODE REPEATLY
11) TS (TRACK SEPARATION)	PRESS TO DIVIDE THE RECORDING TRACK AT TURNTABLE OR TAPE ONE BY ONE DURING ENCODING